

Nissan 350Z 2003-2008 VTX Style 2 Piece Polyurethane Side Skirts Installation

What's Needed:

- M6-1.0x18mm Stainless flat head hex socket bolts
- M6-1.0 Stainless nylon lock nuts
- #8x3/4" Stainless self-tapping metal screws
- 5/64" Metal drill bit
- 7/32" drill bit
- 3M 5952 Double-sided adhesive tape
- 3M Primer 94 adhesive promoter
- 10mm socket & ratchet
- Drill
- Painter's tape
- Trim removal tool

Installation:

1. Remove the OEM side skirts by carefully removing the plastic fasteners located in the front and rear fender wells using a trim removal tool. Once these have been removed, unfasten the 7 10mm bolts along the underside of the skirt. Next, remove the plastic kick plate trim panel just inside the door opening by releasing the push clips with a trim removal tool. This will allow access between the OEM side skirt and chassis. Gently release the 10 plastic clips behind the side skirt with a trim removal tool, being careful as these clips can be brittle.

Note: Completely remove the plastic clips from the chassis side of the vehicle to ensure flush fitment of the new side skirts.

2. Use painter's tape to hold your KBD VTX Style Side Skirts in place to prepare for mounting.
3. Drill 5/64" pilot holes approximately 6"-10" apart on the inner most lip of the KBD VTX Style Side Skirts into the metal chassis. Using #8x3/4" stainless self-tapping metal screws, fasten the inner portion of the skirt to the chassis of the vehicle.



4. Apply 3M 5952 double-sided adhesive tape along the upper lip, behind each end of the KBD VTX Style Side Skirts. Adhere to the vehicle.

Note: Clean the adhesive surfaces with isopropyl alcohol. Then, use 3M Primer 94 or equivalent adhesive promoter for best results.



5. Using a 7/32" drill bit, drill the pre-marked indentations on the ends of the KBD VTX Style Side Skirts.
6. Fasten the ends of the KBD VTX Style Side Skirts with M6-1.0x18mm stainless flat head hex socket bolts and M6-1.0 stainless nylon lock nuts through the new holes and the OEM side skirt mounting points.
7. Under the vehicle, drill 5/64" pilot holes and secure with #8x3/4" stainless self-tapping metal screws





After picture also featuring KBD Nissan 350Z 2003-2008 Nismo 2 Style 1 Piece Polyurethane Front Bumper